

Ensure that the fall on the rooflight matches the fall on your roof/terrace

**IF INCLUDING BLACKOUT BLINDS**

When blinds are selected, plaster up to blind trim

Blackout blind option

When no blind is selected, distance between plaster stop bead and glass to be approx 10mm and must not be in contact with glass

**Lift from here (dedicated drip overhang)**

Roof membrane tucked and sealed under dedicated drip lip. If using torch on felt, cut to size, fold back and pre-heat before applying to the upstand and profile - DO NOT APPLY HEAT TO THE ROOFLIGHT

**Do not lift by glass**

7mm MIN gap

Floor finish

Pre-drill frame and screw fix through purpose made recess as per your step by step fitting guide

EPDM roof finish, for alternative finishes, please refer to your step by step installaton guide

40mm MIN

Stop bead

Silicone bead to be applied all the way around your upstand before lowering your rooflight into place

75mm width timber upstand, minimum height of 25mm.

Arris rail (recommended)

Plywood deck

Plasterboard

Internal sizes taken from here

(size ordered = size of timber structural opening)