

ROOF MAKER

WORLD CLASS ROOFLIGHTS

UPSTAND SURVEY

When the timber upstand kerb is wider than 70/75mm it is important that the built in aluminium kerb for the rooflight finishes flush or with a small overhang to the external timber kerb.

For example if the timber upstand is 100mm wide then the flat step should always be internal not external in order to prevent flashing issues that will prevent rainwater from pooling in order to achieve optimum weather proofing. Rainwater should run off the sides of the aluminium rooflight and flashed timber kerb cleanly.

