

Fixed Flat Rooflight – Blind Fitting Guide

Our SKY-BLIND roof blind frames can be recessed to fully conceal the aluminium outer frame, creating a seamless architectural finish.

To achieve this, the rooflight must be oversized to sit over the structural opening. This creates a recessed ledge, as illustrated in the cross-section details, allowing both the blind frame and compacted fabric (when open) to be hidden within the construction.

Plasterboard should be finished to the indicated positions, ensuring sufficient clearance for the blind to operate freely without obstruction.

The result is a refined, minimal aesthetic — with no visible blind frame. When closed, only the fabric is seen, delivering a clean and high-end appearance.

