Minimum fall 5 (inc roof) to allow water to run off
Maximum fall 15 (inc roof)

IF INCLUDING BLACKOUT BLINDS

When blinds are selected, plaster up to blind trim

Black out blind option

When no blind is selected, plaster stop bead to finish flush with the top of the inside profile (as illustrated)

Do not lift by glass

Pre-formed screw holes within upstand will allow you to fix the unit to your timber upstand with screws provided. This requires you to power the rooflight before opening - refer to step by step installation guide

Maximum 70mm width timber upstand, guide minimumheight of 30mm. Pre-weather the side face of your timber upstand finishing level with the top (as illustrated).
Leave the top face of the timber upstand as exposed timber. IMPORTANT do not exceed 70mm width to avoid compromising drip detail.

Plaster Board

Stop Bead

Apply a generous bead of silicone around the top of your upstand before lowering rooflight into place

Lift from here (dedicated drip overhang)

EPDM roof finish, for altermnative finishes please refer to your step by step installation guide

Arris Rail (Recommended)

Plywood deck

Internal sizes taken from here (size ordered = size of timber structural opening)

ROOF MAKER
WORLD CLASS ROOFLIGHTS

ROOF-Maker
1 Pinfold Road , Thurmaston
Leicester, LE4 8AS
Tel: 0116 350 0030
Tech Line: 0116 350 0012
Email: sales@roof-maker.co.uk

Title: Flat Hinged Double Glazed - Fitting Guildlines

THIS DRAWING IS FOR REFERENCE ONLY. PLEASE REPORTANY DISCREPANCIES TO THE DESIGNER BEFORE ANY WORKS COMMENCE. ALL DIMENSIONS ARE IN mm. ALL DIMENSIONS TO BE CHECKED ON SITE BEFORE ANY WORKS COMMENCE.

Date:	13/05/22		Scale:
Drawn:	JD	Checked: PG	Approx 1:1